



NOTES:

1. COMPLETE FREE BORE. REMOVE AUGER, AND INSERT CARRIER PIPE W/ SPIGOT END.
2. PROVIDE SINGLE PIECE OF CARRIER PIPE FOR ENTIRE SPAN OF FREE BORE WITH NO JOINTS.


  
**Del-Co**  
**Water Co., Inc.**  
 6773 OLENTANGY RIVER RD.  
 DELAWARE, OH 43015

## FREE BORE

REVISED  
 10-11-04

SCALE  
 NTS

PAGE 1 OF 1

D-23