



NOTES:

1. COMPLETE FREE BORE. REMOVE AUGER, AND INSERT CARRIER PIPE W/ SPIGOT END.
2. PROVIDE SINGLE PIECE OF CARRIER PIPE FOR ENTIRE SPAN OF FREE BORE WITH NO JOINTS.



6658 OLENTANGY RIVER RD.  
 DELAWARE, OH 43015  
 PHONE: (740) 548-7746  
 FAX: (740) 548-2089

## FREE BORE

REVISED  
09 OCT 18

SCALE  
NTS

PAGE 1 OF 1

D-23